

# Indicate A Valid Code Entry on the PRX-2, PRX-4 or PRX-5

The PRX-2, PRX-4 or PRX-5 keypads can be used with an entry controller to provide keyless entry to locked doors or gates. In the normal wiring configuration (4 wires), the keypad does not indicate a valid or invalid entry and customers often ask if this is possible. With the addition of a 12 volt DC relay and one more wire to the keypad, the green LED of the PRX-2, PRX-4 or PRX-5 can be configured to turn on following a valid entry. Useful when the strike or mag lock operation is quiet or any time the user needs confirmation that the relay has operated. This diagram shows our ES-1 controller but this also applies to the C-4000, AES-2000, ES-3 or any 26-bit Wiegand controller.

